



FILTER FABRIC FENCE


1. SET POSTS AT REQUIRED SPACING AND DEPTH




2. EXCAVATE A 6"x6" TRENCH UPSLOPE ALONG THE LINE OF STAKES.




3. ATTACH FILTER MATERIAL TO STAKES AND INSTALL IT INTO THE TRENCH.




4. BACKFILL THE TRENCH AND COMPACT THE EXCAVATED SOIL.



EXTENSION OF FABRIC INTO TRENCH.



ALTERNATE V-TRENCH EXTENSION OF FABRIC INTO TRENCH.



GENERAL NOTES:

1. POSTS TO BE SET AT 3-FOOT MAXIMUM SPACING. IF FACTORY PREASSEMBLED FENCE WITH SUPPORT NETTING IS USED, SPACING OF POST MAY BE INCREASED TO 8 FEET MAXIMUM.
2. WHEN TWO SECTIONS OF FILTER CLOTH ADJOIN EACH OTHER THEY SHOULD BE OVERLAPPED 6 INCHES AT THE POSTS, AND FOLDED.

NOT TO SCALE

CITY OF TOMBALL ENGINEERING & PLANNING DEPARTMENT	
FILTER FABRIC FENCE CONSTRUCTION DETAILS	
APPROVED BY COT:	
ENGINEERING & PLANNING DEPARTMENT EFFECTIVE JULY 1, 2010	
SHEET 001 OF 001	DWG NO: COT SWP-01